INNOVATIVE KEY CABINET

MOUNTING INSTRUCTIONS

- 1. Level cabinet in desired location.
- 2. Mark drill holes on wall as shown.
- 3. **Drill holes** using the included multi-purpose drill bit.
- 4. **Fasten cabinet to wall** with supplied anchor bolts and tighten.



Part # I-KC



