## INNOVATIVE WELD TEST STATION

## **ASSEMBLY INSTRUCTIONS**



Install (4) **Total-Lock Caster Wheels** into **Side Frame** as shown.

CASTER WHEELS - P/N 4TLCW SIDE FRAME - P/N 730-011



Bolt **Crosstube** to **Side Frame** using 1/4"  $\times$  3/4" bolts and washers. Repeat for opposite side.

Note: Do not tighten fully until final step.

CROSSTUBE - P/N 730-012




Lay cart flat as shown. Install **Top Shelf** to **Crosstube** using 1/4" x 3/4" bolts and washers. Repeat for opposite crosstube and lower shelf.

**Note:** Smaller wire on top side of shelf



Align upper **Side Frame** and **Table Top** holes as shown and install using 1/4" x 2" bolts and corresponding nuts & washers. Repeat for opposite side.




Install upper **Back Frame** to upper **Side Frames** using 1/4" x 2" bolts with corresponding nuts & washers. Remove emblem from upper back frame. **Fully tighten all hardware.** 

UPPER BACK FRAME - P/N 730-014



Continue on back to complete Innovative Weld Test Station Assembly

UPPER SIDE FRAME - P/N 730-013



**With emblem removed** in Step 5, install **Back Panel** over **Back Frame** by sliding down until bottom of back panel reaches the top of aluminum table.



Install **Side Panels** over **Side Frames** by sliding down until bottom of side panels reach the top of aluminum table.

**Note:** Remove protective film from double-sided tape first.




Install **Coupon Tray** and **Tool Tray** in desired locations on **Side Panels.**Bolt **Vise** on using included hardware.



Screw **Tube Connector** into table top until 5/8" shows beneath table. From beneath the table, thread large nut onto tube connector and tighten.

Install **Post Tube** onto threaded **Tube Connector** and hand tighten.







WWW.INNOVATIVETOOLS.COM